Special Handling is Required for this product. HANDLING & INSTALLATION INSTRUCTIONS

All Natural Wallcoverings are HANDcrafted from natural fibers & Materials. It is specially dyed and there are often slight irregularities in weave & coloration. This provide look that can't be duplicated by conventinal machine made wallpaper. This may be obious because natural fibers may vary in width, this should not be considered as a defect. Natural fibers can & often change color after being on the wall for any length of time and are sensitive with dirt & water. Natural wallcoverings should be cleaned regularly with vacuum brush to remove dirt and dust. Natural wallpaper is sensitive to prolonged contact to water/glue

No Squeeze

1

1

2

3

*

1

4

1

No Roller

3

3

4

3

7.

ONIY

Gentle Hands

Normal Hanging

Reverse Hanaina

- Natural Textiles

[If you see the color variation]

General Guidelines

Confirm that you have the correct items, all material has same run lot number before installation. Inspect the goods carefully.

No claim will be accepted beyond the installation of 3 strips. No labor Claims will be considered.

Wall Preparation

Ensure surfaces are clean, smooth, dry, firm and uniformly colored. If not, necessary remedy works are required.

Walls should be primed with a good quality primer.

Installation

Use a Heavy Duty, Clear, Pre-Mixed, Vinyl, Low Water Content Adhesive.

Apply a ready mix Adhesive to the products evenly , following the instruction of adhesive manufacturer.

Do not use too much adhesive to avoid seam tearing stains on the wallcovering.

You could apply a ready mix adhesive to the wall. (Not to the wallcovering) Adhere product to the wall using a bristled nylon brush or and a plastic sweep. Smooth until all air bubbles are removed.

Never allow the adhesive to get on face and/or edges of the material.

- * DO NOT put the goods onto soiled floor.
- * DO NOT crease the goods.
- * DO NOT get paste on the face of the product.
- * USE Factory Edges on butt-Joints
- * Cut with a very sharp, single edge razor blade.
- * DO NOT have longer relaxing time.

* Wipe off excess paste immediately with soft damp cloth. Do not scrub and rub.

* Hang sequentially prepared sheet of wallpaper. (*Please see below diagram.)